

Mr. McGregor's Fence®

Installation Photos



Step 1: Surrounding the garden with the weed barrier



Step 2: Inserting the 27" fiberglass posts into the ground.



Step 3: 27" post woven through the barrier fence



Step 4: Cutting the barrier fence to fit.



Step 5: Sliding on the insulator



Step 6: Spacing the insulators 4" apart



Step 7: Inserting the corner 18" post to a depth of 9"



Step 8: Stringing the first row of fence wire



Both wires strung. The fence is finished and awaiting an energizer.